

Assorted Tips & Tricks

To put the BlackBerry in Standby mode: press and hold the Mute button (top). While in Standby mode, key presses do nothing. Press the Mute button again to return to normal use.

To view contacts from the telephone screen: press and hold the Send button to open your contact list.

To see a sender's email address in a message: open the message. Scroll to the sender's name at the top, located beside the **From:** field. Press Q to display their email address, and press Q again to display their name.

To insert the current date while typing: type L, then D, and press SPACE.

To insert the current time while typing: type L, then T, and press SPACE.

Nevada Learning Series Quick Reference Guides


6 page tri-fold and PDF guides for Bold 9000, Pearl 81xx, Curve 83xx, 87xx, 88xx, 957, Enterprise Server 4, and more!

Visit our website at www.nlearnseries.com

Caller ID Pictures & Ring Tones


You can link custom pictures or ring tones to your BlackBerry contacts to quickly identify who is calling.


To Add a Custom Contact Picture

Open your Address Book and select the desired contact from the list. Press the Menu key  and choose **Add Picture**. Use the trackball to select a picture that you've taken with the BlackBerry camera, or choose **Camera** to take one now. The **Contacts** folder contains sample images you can use as well.

When you have selected a picture, use the trackball to move the crop box as needed. Click the trackball to access other cropping options from a menu, such as **Zoom** or **Rotate**. Choose **Crop and Save** to finalize your custom contact picture.

To Add a Custom Contact Ring Tone



Open your Address Book and select the desired contact from the list. Press the Menu key  and choose **Add Custom Ring Tone**. Use the trackball to select a ring tone from your BlackBerry.

To preview a selected ring tone: press the Menu key  and choose **Play**. Press the Escape button to return to the ring tone list.

To choose a ring tone: select it and click the trackball.



Customizing Your BlackBerry

Screen Font & Trackball Sensitivity



From the home screen, press the Menu key  and choose **Options** . Choose **Screen/Keyboard**. Change the **Font Family**, **Font Size**, and **Font Style** fields to suit your preferences. Scroll down to the **Trackball** section and change the **Horizontal Sensitivity** and **Vertical Sensitivity** fields as desired (bigger numbers = more sensitive). Save your changes.

Assign Functions to Convenience Keys

By default, the convenience keys on each side of your BlackBerry open Voice Dialing (left key) and the Camera (right key).

To change convenience key assignment: from the home screen, press the Menu key  and choose **Options** . Choose **Screen/Keyboard**. Click a convenience key field (e.g. **Right Side Convenience Key Opens**) and choose a new function from the list. Save your changes.

Spell Checking

From the home screen, press the Menu key  and choose **Options** . Choose **Spell Check**. Check the **Check Spelling As You Type** option to have your BlackBerry spell check your messages, or choose **Custom Dictionary** to add new words.

Research In Motion®

BlackBerry™

Bold 9000



Pocket Guide

NEVADA
LEARNING SERIES™